VENUCAST™

Lite Aura

Auracast Headphones for Public Spaces



Interactive User Guide

Version 2.5

Start Listening

Activate Free 24-Month Warranty

< Back



Main Menu

1. Join Open Broadcast

2. Search or Switch Broadcasts

3. Buttons & Indicators

4. Power & Charging

5. Troubleshooting

6. Register & Support

Rate This Guide

Next

< Back

Menu

1. Join Open Broadcast

The headphones can join any open Auracast broadcast.

How to: Turn **ON** your headphones.
→ LED blinks orange. (Searching for a nearby broadcast)

✓ **Joined:** LED turns solid orange.



Next

< Back

Menu

2. Search/Switch Broadcasts

To search for new broadcasts:

Double press the **SCAN** button.
→ LED blinks orange rapidly.
✔ **Joined:** LED turns solid orange.

If multiple public broadcasts are available nearby, the headphones save up to **8 available broadcasts**.

To switch a different broadcast:

Hold the **CH** button to switch broadcasts.



Next

< Back

Menu

3. Buttons & Indicators



A LED

- Solid orange → Joined a broadcast
- Blinking orange rapidly
  → Searching broadcasts

SCAN Button

- Search broadcasts

CH Button

- Switch broadcast

Next

< Back

Menu

4. Power & Charging

- **USB-C** power: 5V, 1-2.4A
- Charging: LED stays solid red.
- Fully charged: LED turns **off** (~2.5h).
- Playtime: Up to 35 hours.



Next

< Back

Menu

5. Troubleshooting

- No sound or not joined?

  → Double press SCAN.



Next

< Back

Menu

6. Register & Support

Register Your Product

Extended warranty & get updates.

Get 24M Warranty

Need help? Contact Us

Email

support@venucast.com >

Call

USA (Toll Free)

+1 888 464 0168

Other Regions >

Chat >

Next

< Back

Menu

Did this guide help you?

Your feedback goes directly to our team.

It helps us improve future guides and products.

Takes less than 10 seconds.

Helpful

It's OK

Need Help

Thank you for helping us improve.